

Character Entry Chart

Use the chart below to locate the letter that allows you to enter text on a display and create customised messages.

Example: To enter the name MARY, you would use the dial pad to enter the number series:

M=61, A=21, R=72, Y=93

A	21
B	22
C	23
D	31
E	32
F	33
G	41
H	42
I	43
J	51
K	52
L	53
M	61
N	62
O	63
P	71
Q	N/A
R	72
S	73
T	81
U	82
V	83
W	91
X	92
Y	93
Z	N/A